

3/4" ball drain cock set

Description

High-quality design for horizontal storage of 20 l canisters with thread size DIN 61 outside.

Application

Installation of the ball drain cock set:



Step 1: Wrap the thread of the ball cock with the PTFE thread sealing tape eight to ten times.

Step 2: Screwing in the ball drain cock: **Important: When threading, make sure that it is threaded straight. Otherwise the plastic thread can be destroyed!**

Step 3: Screw the drain cock into the canister cap with two turns.

Step 4: Insert disposable flat seal into the nut.

Step 5: Screw the canister cap onto the canister thread until it is tight. If the ball drain cock is not pointing vertically downwards, continue turning clockwise until the drain is pointing vertically downwards (6 o'clock position). **Important: The ball cock must not be turned counterclockwise, as this will cause the ball-cock-canister cap connection to leak.**

If the ball-cock-canister cap connection leaks, the tap must be turned completely out of the cap. Remove the old PTFE sealing tape completely and screw it back into the canister cap with the new PTFE sealing tape.

When unscrewing from the empty canister and screwing onto the new canister, ensure that only the canister closure is turned and not the tap.

Before screwing onto the new canister, insert a new disposable flat seal into the canister closure.

Available pack sizes

1 pcs Bag plastic 29122
D

Our information is based on thorough research and may be considered reliable, although not legally binding.